## <u>NAVSEA</u> STANDARD ITEM

*FY-28* 

<u>ITEM NO:</u> 009-047 <u>DATE:</u> 01 OCT 2025 CATEGORY: II

- 1. SCOPE:
  - 1.1 Title: Gate Valve; repair
- 2. REFERENCES:
  - 2.1 S9086-CJ-STM-010/CH-075, Fasteners
- 2.2 S9253-AD-MMM-010, Maintenance Manual for Valves, Traps, and Orifices (Non-Nuclear), User's Guide and General Information
  - 2.3 *S9086-RK-STM-010/CH-505*, *Piping Systems*
- 2.4 S9086-RJ-STM-010/CH-504, Pressure, Temperature and Other Mechanical and Electromechanical Measuring Instruments
- 3. <u>REQUIREMENTS</u>:
  - 3.1 Matchmark each valve part.
- 3.2 Disassemble, clean internal and external surfaces free of foreign matter (including paint), and inspect each part for defects.
- 3.2.1 The removal of body-bound studs only to determine the condition of threads is not required.
- (I) or (V) "TORQUE TEST" (See 4.3)
  - 3.3 Torque test each body-bound stud in accordance with Section 075-8.6.3.2(d) of 2.1.
  - 3.4 Repair valve as follows:
- 3.4.1 Straighten stem to within 0.002-inch total indicator reading. Polish stem to a 32 Root-Mean-Square finish in way of packing surface and remove raised edges and foreign matter.
  - 3.4.2 Chase and tap each exposed threaded area.

1 of 3 ITEM NO: <u>009-04</u>

FY-28

- 3.4.3 Dress and true each gasket mating surface.
- 3.4.4 Machine, grind, or lap and spot-in gate to seats (including backseat) to obtain a 360-degree continuous contact.
  - 3.4.4.1 Inspect contact using blueing method.
- 3.4.4.2 Transfer line must not exceed 3/16-inch in width and must appear within the lower 75 percent of the gate seating surface.

## (I)(G) "VERIFY LEVEL I PARTS AND CLEANLINESS"

- 3.5 Assemble each valve installing new each packing, each gasket and each fastener for those removed in 3.2 in accordance with the manufacturer's specifications.
- 3.5.1 Pack feedwater, condensate, and steam valves with valve stem packing conforming to MIL-P-24503/MIL-DTL-24583 combination in accordance with Chapter 6 of 2.2.
- 3.5.2 Pack valves of systems other than feedwater, condensate, or steam with valve stem packing conforming to MIL-P-24396, Type B.

## (V)(G) or (I)(G) "HYDROSTATIC TEST (See 4.4)

- 3.6 Hydrostatically test shell of valve in accordance with paragraph 505-11.3 of 2.3 and Chapter 7 of 2.2 for evidence of external leakage and/or deformation. Allowable external leakage and/or deformation: None.
  - 3.6.1 Hydrostatic test equipment must have the following capabilities:
    - 3.6.1.1 Manual overpressure protection release valve.
- 3.6.1.2 Self-actuated and resetting relief valve with a set point no greater than 100 PSIG above the test pressure or 10 percent above the test pressure, whichever is less.
- 3.6.1.3 Master and backup test gauges with gauge range and graduation in accordance with Table 504-6-1 of 2.4. The backup gauge must be cross-checked to the master hydrostatic test gauge up to the maximum test pressure just prior to start of testing. Master and backup gauges must track within 2 percent of each other.
- 3.6.1.4 Protection equipment must be accessible and test gauges must be located where clearly visible and readable to pump operator and inspector.

(V)(G) or (I)(G) "SEAT TIGHTNESS" (See 4.4)

2 of 3 ITEM NO: <u>009-04</u>

- 3.6.2 Test for seat tightness alternately on each side of gate for double seated valves, and on outboard side only on single-seated valves, with the opposite side open for inspection.
- 3.6.2.1 Do not exceed the handwheel closing force specified in Table 505-11-2 of 2.3.
- 3.6.2.2 Test must be continued for a minimum of 3 minutes if there is no evidence of leakage, or in the event of visible leakage, until accurate determination of leakage can be made. Maximum allowable leakage: 10 cubic centimeters (cc) per hour, per inch of nominal pipe size; 10 cc maximum per hour for valve sizes less than 1-1/2 inches.

## 4. NOTES:

- 4.1 The test pressures of **3.6** and 3.6.2 will be specified in Work Item.
- 4.2 Repair of valve operating gear will be specified in Work Item.
- 4.3 The paragraph referencing this note is considered an (I) if the valve is Level I. If the valve is not Level I, the paragraph is considered a (V).
- 4.4 The paragraph referencing this note is considered an (I)(G) if the valve is Level I. If the valve is not Level I, the paragraph is considered a (V)(G).
  - 4.5 Test medium will be specified in Work Item.

3 of 3 ITEM NO: <u>009-047</u>